

## Plastic Stickon Installation Instructions

### 1. Temperature

- The ideal application temperature range is from 60°F to 90°F (15°C to 32°C)
- Application is not recommended if the surface temperature is below 50°F (10°C)

### 2. Prepare Surface

- Ensure that the surface is clean, oil free and dry

### 3. Install Marker

- Remove the paper backing from the stickon
- Apply marker to the clean surface
- Press the marker firmly against the surface and hold for a few seconds to promote adhesion
- When finished, remove the plastic stickon protection film from the surface of the stickon

### 4. Finish

- Keep marker dry for 24 hours to allow the adhesive to fully cure
- Use non-abrasive cleaners